

# BW-50

"L" shaped precast concrete curbs.  
#161013



## Manual

■ Green up the roof!



### Application:

Used for the clear demarcation of gardening spaces and paved areas. It could be good tool for creation a variety of garden forms.

### Installation instructions:

Prior to installing the curbs, place a minimum 2 inches deep bedding of 5/8" minus washed crushed stone on top of the heavy duty drainage board in the areas where the curbs will be installed. Thickness of laying course should be uniform to insure an even surface. Bedding material could be screened sand, concrete sand or crushed rock. Using of Pea gravel, or native soil are not recommended. Spread and consolidate the bedding as necessary to form a level base for the curbing. After the bedding has been approved install the curbing as shown on the approved plans. Use only proper lifting gear to handle or place concrete section. Cover the curb joints on the growing media side with self adhering bitumen tape.

### Installation Tools:

General garden building tools. Cut curbing where necessary with diamond impregnated saw blade. Compact bedding with a 200-300 lb. landscape roller or hand held compactor.

### Installation Photos:

Reviewed: 2015-06-09 15:20:04

## DIADEM USA, Inc.

8795 SW Tualatin Sherwood Rd #1005, Tualatin, OR 97062  
Email: [info@diademusa.com](mailto:info@diademusa.com); Web: [www.diademusa.com](http://www.diademusa.com)