

# FLW-1000

Root barrier layer  
#340104



## Manual

■ Green up the roof!



### Application:

The product is particularly recommended for additional protection against water and root breakthrough on extensive roofs. Ideal when renovating smaller garage roofs or outbuildings and a perfect answer for lining planting beds.

### Installation instructions:

- Cold welding:
- Both hot and cold welding is suitable for joining the seams
- Apply the welding agent with a brush
- Press the seam together and roll at once with a silicon roller
- Hot welding:
  - At least a 20 mm clean and dry overlap is necessary
  - Allow the material to warm up
  - Lead the welding nozzle over the 20 mm overlap and pay particular attention to the edge of the upper layer. (The nozzle must also travel 2-3 mm beyond the edges to be joined)

### Installation Tools:

Sharp blade, Cutter

### Installation Photos:



Reviewed: 2015-02-27 14:03:34

### DIADEM USA, Inc.

8795 SW Tualatin Sherwood Rd #1005, Tualatin, OR 97062  
Email: [info@diademusa.com](mailto:info@diademusa.com); Web: [www.diademusa.com](http://www.diademusa.com)