

BW-30

L-shaped precast concrete curbs.
#161002



Manual

■ Green up the roof!



Application:

The BW-30 is a great tool for adding creative variety to green roof & garden systems. Used for the clear demarcation of garden spaces and paved areas.

Installation instructions:

Prior to installing the curbs, place a minimum 2 inches deep bedding of 5/8" minus washed crushed stone on top of the heavy duty drainage board in the areas where the curbs will be installed. Thickness of laying course should be uniform to ensure an even surface. The use of pea gravel, or native soil are not recommended for bedding. Spread and consolidate the bedding as necessary to form a level base for the curbing. After the bedding has been finalized install the curbing as shown on the approved plans. Use only proper lifting gear to handle or place each concrete section. Cover the curb joints on the growing media side with self adhering bitumen tape.

Installation Tools:

- Grade stakes □
- Wide blade masons chisel □
- Masons string (twine) □
- Stiff bristle street broom □
- 3-5 pound hammer □
- Hard tooth garden rake □
- Chalk line □
- 25 ft. Measure tape □
- Small pry bar □
- 4 ft. Level □
- Wheelbarrow □
- Pavercart□
- Trowel □
- Flat shovel for sand □
- Marking crayon or chalk □
- 3hp to 5hp plate compactor (not a jumping jack) □
- Paversplitter□
- Cut off saw with diamond impregnated blade□
- Lifting clamp

Installation Photos:



DIADEM USA, Inc.

8795 SW Tualatin Sherwood Rd #1005, Tualatin, OR 97062
Email: info@diademusa.com; Web: www.diademusa.com