


VLS-550

Water Retention Mat
#320402



Manual

■ Green up the roof!

	<p>Application:</p> <p>VL geotextiles have many different uses on green roofs but their main functions are filtering and mechanical protection. VLS geotextiles are water retentive and protect too. Manufactured from a mixture of threads, without thermal treatment. Mass per unit area 16 oz/sqy</p>
<p>Installation instructions:</p> <p>Remove debris and check that the surface is clean and sound. Roll out the geotextile and leave at least 12" overlap at the ends and 4" at sides. These sheets should be weighted if left exposed. Wetting the sheets provides a degree of weight but if left for longer periods sandbags or paving slabs should be used.</p>	
<p>Installation Tools:</p> <p>Scalpell, Cutter</p>	
<p>Installation Photos:</p>	

Reviewed: 2015-07-03 13:41:03

DIADEM USA, Inc.

8795 SW Tualatin Sherwood Rd #1005, Tualatin, OR 97062
Email: info@diademusa.com; Web: www.diademusa.com