


VLS-800

Capillary fabric for protection and water retain functions
#320426



Manual

■ Green up the roof!

	<p>Application:</p> <p>The VLS materials are suitable to absorb larger quantities of water due to its mixed fibers, thus we recommend to install them under intensive vegetation, or when higher water retention capacity is required due to the characteristics of the project.□</p>
<p>Installation instructions:</p> <p>Remove debris and check that the surface is clean and sound. Roll out the geotextile and leave at least 12" overlap at the ends and 4" at sides. These sheets should be weighted if left exposed. Wetting the sheets provides a degree of weight but if left for longer periods sandbags or paving slabs should be used.</p>	
<p>Installation Tools:</p> <p>Scalpell, Cutter</p>	
<p>Installation Photos:</p>	

Reviewed: 2019-07-25 11:03:53