

FLW-1000

Root barrier layer
#340104



Manual

■ Green up the roof!



Application:

The product is particularly recommended for additional protection against water and root breakthrough on extensive roofs. Ideal when renovating smaller garage roofs or outbuildings and a perfect answer for lining planting beds.

Installation instructions:

- Cold welding:
- Both hot and cold welding is suitable for joining the seams
- Apply the welding agent with a brush
- Press the seam together and roll at once with a silicon roller
- Hot welding:
- At least a 20 mm clean and dry overlap is necessary
- Allow the material to warm up
- Lead the welding nozzle over the 20 mm overlap and pay particular attention to the edge of the upper layer. (The nozzle must also travel 2-3 mm beyond the edges to be joined)

Installation Tools:

Sharp blade, Cutter

Installation Photos:



Reviewed: 2015-02-27 14:03:34

DIADEM USA, Inc.

8795 SW Tualatin Sherwood Rd #1005, Tualatin, OR 97062
Email: info@diademusa.com; Web: www.diademusa.com