

FLW-1000-PE

Root barrier layer
#340104U3



Manual

■ Green up the roof!



Application:

The product is particularly recommended to protect conventional waterproofing layers against root penetrations on extensive and intensive roofs. Ideal for lining planting beds. Please contact us for finding the best root barrier product which fits your plant selection.□

Installation instructions:

- Cold welding:
- Both hot and cold welding is suitable for joining the seams
- Apply the welding agent with a brush
- Press the seam together and roll at once with a silicon roller
- Hot welding:
- At least a 20 mm clean and dry overlap is necessary
- Allow the material to warm up
- Lead the welding nozzle over the 20 mm overlap and pay particular attention to the edge of the upper layer. (The nozzle must also travel 2-3 mm beyond the edges to be joined)

Installation Tools:

Sharp blade, Cutter

Installation Photos:

Reviewed: 2021-11-06 23:25:24

DIADEM USA, Inc.

8795 SW Tualatin Sherwood Rd #1005, Tualatin, OR 97062
Email: info@diademusa.com; Web: www.diademusa.com